




Armpad Rotate



Armrest Height



Chair Height Adjustment



Tilting Backrest



Armpad Sliding



Lumbar Height Adjustment



Seat Depth Adjustment



CURVE

User Guide



Gaslift / Chair Height Adjustment



Locking Adjustment



Tension Adjustment